

# Cobra / Vodafone Automotive - Touch Car Immobiliser



MANUALE UTENTE  
USER MANUAL  
GEBRAUCHSANLEITUNG  
NOTICE D'UTILISATION  
GEBRUIKERSHANDLEIDING  
MANUAL USUARIO

Art. 8510

GB

## PRODUCT DESCRIPTION

Passive arming immobiliser, controlled by antiscanner electronic key.

## ARMING THE SYSTEM

When the immobiliser will automatically arm itself after 60 sec. the ignition has been turned off:

- The engine cut will be activated
- The LED will blinking

## DISARMING THE SYSTEM

When inserting the electronic key into the control panel mounted under the dash:

- reset of the engine's functions
- extinction of the LED

After 60 sec. by the disconnection if the check control has not restarted, the immobiliser will insert again.

GB

## USER NOTES

- 1) **The electronic key is the only means to disarm the system.**
- 2) A built in safety circuit ensure that immobiliser can not be armed while the vehicle's engine is running.
- 3) As the electronic key do not require battery and maintenance they are completely sealed.
- 4) For any failure of the system, or in case of loss of one of the key, contact your installer.

## AUTO-LEARNING PROCEDURE FOR NEW ELECTRONIC KEYS

Follow this procedure to replace the electronic keys:

With the immobiliser disarmed, proceed as follow:

- Turn the starter key on and then off for 3 times then turn on the starter key again.

**All the operation must be carry out within 7 s.**

- LED comes on in a fixed way signalling that the immobiliser is ready to store the electronic keys.
- Put a key which was already stored in connection with the control panel, then the other keys to be stored.
- As soon as the key code is stored the LED goes off for 1 s.

The autolearning procedure can be interrupted at any time by simply turning the ignition key ON. It will automatically interrupt itself when 4 keys are stored (max number of keys).

WARNING:

- The operations of auto-learning of the new electronic keys must be realized only with the immobiliser disarmed.
- In case of loss of all the keys is not possible to execute the auto-learning procedure.
- You can store up to 4 keys max.

GB

## PRODUCT DESCRIPTION

Immobiliser unit commanded by antiscanner electronic key, passive arming, dual ignition cut, "Fail Safe", auto learning of electronic key.